

10337H

VR1 VR2 VR3
100K 100K 100K



VR4 VR5 VR6
100K 100K 100K

GND
5V
D5
D6
D7
D8
A0
A1
A2
A4
A3
A5

PINS FROM ARDUINO BOARD

R1
56K



R2
56K



R3
56K



R4
56K



S4



S3



S2



S1

S1-S4 = TACTILE SWITCH